



CABINET PARTS


Illus.	Part		Illus.	Part		lllus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
						-		
1		Literature Parts	8	489399	Screw	26		Filter, Water
	2317085	Use & Care Guide	9	2006442	Mounting Bracket,	27	2266880	Bushing-Arm,
	2307360	Energy Label			Grill			Extension
	2306322	Service & Wiring	10	2005921	Screw	28	2006388	• *
		Sheet	11		Cap, Grommet			(Bottom)
	2302865	Service Sheet,	12	2004514		29	2005101	
		Main Control	13	2204516	Tube, Drain			Refrigerator
	628370	Modular Icemaker			Condensate	30		Screw, 8-18 x 1/2
		Service Sheet	14	2207470	Shim-Hinge, Door	31	489282	
	2307890	Installation	15	2209090	Clamp, Filter	32	2209024B	Skirt, Grille-
		Instructions			Housing			Bottom
			16		Clamp, Tube	33	2006346	
2		Cabinet (Not A	17		Screw, Door Stop	34	2215889B	Grille Base,
		Serviceable Part)	18	2257644	Hinge, Door			Front
3	2005004	Grommet, Crossover			Refrigerator Top	36		Cover, Air Duct
		Tube	19	2005783	Cam-Closer,	37		Grommet, Wiring
4	1112023	Roller, Front &			Door	38		Arm, Extension
		Rear (4)	20	1157158		39		Bracket, Switch
5		Support, Leveler	21	2006617	Bracket, Support	40		Cover, Switch
		Assembly			Door	42		Cap, Water Filter
		Refrigerator Side	22	2300082		43		Screw (4)
	2004505	Freezer Side	23	2209022	Housing, Water	44		Screw, 8-18 x 3/8
6	2005006	Grommet, Wiring			Filter	45		Switch, Rocker Arm
7	2005007	Grommet,	24	2004517	Spring, Door	46	9791833	
		Flexible			Closure	49	2221070	Clamp, Tube
			25	486194	Screw	1		

CABINET AND BREAKER TRIM PARTS



TOP GRILLE AND UNIT COVER PARTS






LINER PARTS

Illus.	Part		Illus.	Part	•	Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
			l					
1		Liner,	17	2221296	Air Baffle	32		Screw, 8-18 x 3/8
		Refrigerator	١		Assembly	33	2302715	Shield, Light
_		(Not Servicable)	18	2215503		35	2209204	Clip, Thermistor
2		Liner,Freezer	19		Wiring Channel	37		Control Panel
		(Not Servicable)	20	2309303		38	2257521	Overlay, Control
3	2215610	,			Freezer			Panel
		Exchanger			(Includes Item 49)	39	2302913	Circuit Board
4	2215827		21	2306391				(User Interface)
		Left Side			Assembly	40	2303938	Însert,
5	2005931		22	1116793	Cover, Thermistor			Control Box
		Right Side	23	2188820	Thermistor			(User Interface)
6	2171846	Release Valve	24	2209208	Drain Tube,	42	2162085	Socket, Light
7	487539	Screw, 8-15 x 1/2			Condensate	43		Light Bulb
8	486194	Screw	25	2215530	Insulation, Baffle	44	2187424	Harness, Control
9	2223986	Motor, Grommet	26	2215531	Cover, Air			Box
10	2006148	Wiring Channel,			Diffuser	45	8201534	Cover, Wiring
		Freezer Rear	27	2306386	Heater-Tube,			Freezer Light
11	2215844	Foam, Fan Shroud			Drain	46	1115375	Clip, Wiring
12	2215910	Grommet, Flexible	28	2204538	Insulation, Tube	47		Switch, Rocker
13	2215606	Shroud, Evaporator			Drain	48		Wiring Cover,
		Fan	29	2204537	Cover, Tube			Icemaker
14	2169142	Blade, Fan			Drain	49	2309301	Defrost Bi-Metal
15	2259385	Motor, Fan	30	486194	Screw	50		Diffuser Assembly
16		Retainer,	31	2215835	Housing, Switch	51	2221121	
		Fan Motor			3,	•		Control Box
						52	489006	


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

Illus. No.	Part No.	DESCRIPTION
1		Slide, Freezer
'		Basket
	2307978	
	2307977	Left Side
2 4	2006475	
4		Spacer, Crisper
	2256443	0
_	2256442	
5 6	2179404 2221071	
6 7	2221071	Bracket, Freezer
•		Basket
	2257327	Right Side
	2257326	
12	2257562	
4.0		Side
13	2256474	
14	8533929	Crisper Pan Screw
15	0000929	Slide, Crisper
10	2302952	
	2302953	
16	2302788	Support, Crisper
		Cover
17	8533928	
18	2258973	Shelf (4)
19	2257563	Trim-Glass, Side
21	2302839	
29	2256375	Cripser Pan
		Assembly
		(Includes #30)
30	2256374	,
00	0057540	Crisper Pan
33	2257548	,
37	2302837	Deli Pan Crisper Shelf
31	2302031	Assembly
38	2257564	
		Rear
39		Trim-Glass, Front
		(Not Serviceable)
40	2302796	Trim-Glass, Rear
43	0000050	Slide, Deli
	2302950 2302951	Left Side Right Side
44	2302931	Spacer, Deli
7-7	2257531	Left Side
	2257532	Right Side
47	2257535	Deli Pan
		Assembly
40	000=11=	(Includes #33)
48	2005410	Ladder, Shelf (4)
49	2006475	Screw,

FREEZER DOOR AND BASKET PARTS




FREEZER DOOR AND BASKET PARTS

Illus No.	. Part No.	DESCRIPTION
1	2300085	Freezer Door Panel (Includes Item 9)
2 3 4 5	2204525 2207429 2207415 3190699	Divider, Basket Clamp, Divider Nut, Crimp Screw
6 7 8	2258903 2258901X 2258902X	Trim-Door, Corner Trim-Door, Side Trim-Door,
9	2300185	Top & Bottom Door Gasket, Magnetic
10	2259363X	Cover-Screw, Top & Bottom
12 13 14	2204542 2259364X	Roller Cover–Screw, Side Screw, 8–15 x 1/2
15	8281250 2257426	Stainless Steel Bracket Assembly, Freezer Basket
17 18 19 20 21 22	2257442 2174124 2207454 2207471 3400507 2257331	Basket, Upper

REFRIGERATOR DOOR PARTS

For Model: KBRO36FMX02 (Etched Aluminum)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

Illus.	Part	
No.	No.	DESCRIPTION
1	2300083	Refrigerator Door (Includes
		Item 9)
2	2259362X	Cover-Screw,
0	0000040	Handle Side
3	2266912	Hinge Assembly, Top
4	2256381	Spacer–Hinge,
_	400000	Top
5 6	489282 2302927	Screw, 10–32 x 3/4 Hinge Assembly,
U	2502521	Bottom
7	2258908X	Trim-Door, Handle
8	2257692X	Side Trim-Door, Hinge
0	22310327	Side
9	2300184	Door Gasket,
11	2250264V	Magnetic
11	2259361X	Cover-Screw, Hinge Side
12	2005982	Gasket (2)
13	2257647	Spacer-Hinge,
14	2258900X	Bottom Trim–Door, Bottom
15		Screw, 8-15 x 1/2
	8281250	Stainless Steel
16 17	2258903 2257699X	Trim-Door, Corner Trim-Door, Top
18	2005482	Tube, Door
		Shelf
19	2005417	Shelf, Door (2)
20 21	489276	Screw, 8-18 x 3/4 End Cap, Left
22	2005542 2005541	End Cap, Lend End Cap, Right
23	2003341	Tube, Door
		Shelf (Gallon)
24	2259360X	Cover-Screw, Top
26	2005983	Door, Utility Bin (2)
		(Includes Item 12)
27	2006154	Door Shelf,
20	0465700	Gallon Butter Troy
28	2165792	Butter Tray

UPPER UNIT PARTS




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER UNIT PARTS

IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	2200057	Inventor Day		0.4.0=0.00	140			
1 2		Inverter Box	18		Wire, Jumper	Follo	wing P	arts Not Illustrated
2	489373	Screw, Compressor	20		Wire Tie		-	
^	0000007	Mounting (4)	21	2252363		and O	ptionai	Parts Not Included
3	2302967		22	487522				
		(Includes Items	23		Motor, Fan		978025	Valve, Access
		6, 9 & 21)	24		Blade, Fan			(1/4")
		(Also Order	25		Orifice, Fan		978026	Valve, Access
		876765 Tube Kit)	27	8281160				(5/16")
4	2257354	Housing, Control	29	486692	Speed Nut		978027	Valve, Access
		Board	30	2307907	Grommet, Edge			(3/8")
5		Bracket, Fan Motor	31	2259302	Tube, Transition		978028	Valve, Access
6		Grommet, Mounting			(Condenser/Drier)			(1/2")
7	2266803	Shroud, Condenser	32	2000645	Śleeve,		978029	Valve, Access
		(Right)			Condenser			(5/8")
8	2302969	Bracket, Switch	34	2194319	Process, Tube		978030	Valvé, Access
9	2215676	Terminal Cover	35	486194				(3/4")
10	2302973	Shroud, Condenser	36	2209495	Cover, Fan		876764	· Valve, Access
		(Left)	37		Cover, Condenser			(3/16")
11	2307028	Control Board	39		Service Cord			(== -)
12	2203075	Spacer (5)	41		Clamp, Cord			
13		Bracket, Inverter	42		Switch, Power	REFE	RIGERA	NT CHARGE
		Box	'-		Disconnect			<u></u> 0-
15	1157158		43	487294	Screw, Ground			5.75 oz.
16	2259307	Condenser	45		Wiring Harness,			(R-134A)
17	943447	Grommet (4)	.	2.07021	Unit Compartment			(,
		- ' (/			C Comparanont			




LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

Illus.	Part	
No.	No.	DESCRIPTION
1	2313922	Tube, Transition
_		(Condenser)
2	2259304	Tube, Transition
_		(Drier/Restrictor)
3 6 7	486194	Screw
6	2259303	Suction Tube
7	2207486	Heater, Defrost
_		(Rear)
9	2259329	Heater, Drain Pan
10	2209450	Hanger, Heater
11	2005908	Shield, Drain Pan
12	2204543	Support, Heater
13	2259474	Tube, Discharge
16	2306095	Evaporator
17	2207485	Heater, Defrost
		(Front)
18	2204510	Clamp, Heater (2)
21	2187715	Wire Tie
22	2215691	Clip, Heat
		Exchanger
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	Left
	1113207	Right
28	2215648	Damper, Heater

ICEMAKER PARTS



ICEMAKER PARTS

Illus. No.	Part No.	DESCRIPTION		
1	2204597			
2	2221240	Heater, Fill Tube		
3 4	489115			
4	2300104	Cover, Bottom Electrical		
5	628379	Clip, Fuse		
6	2214613			
7	2317093	Water Inlet		
		Tube Assembly		
8	1106508			
9	2302719	Tube, Filter		
		Outlet		
10	2313917	Valve, Solenoid		
11	2187683	Jumper, Heater		
		Fill Tube		
13	2221231	Heat Shield		
15	489348			
		Valve		
16	488946	•		
17	2187715	,		
		Icemaker		
18	2257538			
20	628228	Mold & Heater		
		(Also Order		
		542638 Silicone		
		Grease)		
21	626676	Motor		
22	628356	Cup-Water Fill		
23	627843	Ejector		
24	2182124	Ice Striper		
25	2195914			
26	627796	Retainer		
27	607005	Thermostat (2)		
27	627985	Thermostat (Also Order		
		542639 Cement		
28	8533917	Alumilastic) Screw		
30	489276			
	2314015			
31 34	489464	Shut Off Arm		
35	626678			
33	020070	(Includes Items		
		21 & 41)		
37	2306151	Water Valve		
31	2000101	Mounting Bracket		
41	489136	Screw (2)		
43	486194			
100	2316702			
		Assembly		